

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Steps

- 1) Attach lower horizontal extrusions [5,6,7] between vertical assemblies as shown.
- 2) Attach verticals [3a,4a] atop lower horizontal [7].
- 3) Hang assembled door on hinges on vertical [1] as shown. Refer to *Door Attachment* detail.
- 4) Slide front insert between verticals [3a,4a] as shown.
- 5) Attach upper horizontal extrusions [5,7] between vertical assemblies and on top of infill as shown.
- 6) Velcro shelf support to inside of pedestal, then set internal shelf on top of supports.
- 7) Place counter top on assembled pedestal.

Item	Qty.	Description
1	1	38" Vertical Extrusion w/ Door Hinges
2	1	38" Vertical Extrusion w/ Door Stop
3	1	38" Vertical Extrusion
4	1	38" Vertical Extrusion
5	2	22.0197" Horizontal Extrusion
6	4	12.5" Horizontal Extrusion
7	2	25.639" Curved Extrusion

